

MARK PARTS ARE LOCATED ON MAIN AMP PC BOARD (B) (AB-3502B)

MAIN AMP PC BOARD (A)/(B) (AB-3502A/B)

NOTE
 UNLESS OTHERWISE SPECIFIED
 ALL RESISTORS IN OHMS 1/4W(J)
 ALL CAPACITORS IN μF 50WV(Z)

WARNING: Δ INDICATES SAFETY CRITICAL COMPONENTS. FOR CONTINUED SAFETY, REPLACE SAFETY CRITICAL COMPONENTS ONLY WITH MANUFACTURER'S RECOMMENDED PARTS.
AVERTISSEMENT: Δ IL INDIQUE LES COMPOSANTS CRITIQUES DE SÛRETÉ. POUR MAINTENIR LE DEGRÉ DE SÛRETÉ DE L'APPAREIL, NE REMPLACER LES COMPOSANTS Δ QUE PAR DES PIÈCES RECOMMANDÉES PAR LE FABRICANT.

**AA-1135L
 MAIN AMP
 SCHEMATIC DIAGRAM
 NO. 2-2 156064**

1 C 8
2 C 9
3 C 10
4 C 11
5 C 12
6 C 13
7 C 14
8 C 15

LA-930

PHONO J4-1

FM
75 OHMS
300 OHMS
AM

ANTENNA

ANT 501
BAR ANTENNA

M 501
PRESET TUNING METER

M 502
SIGNAL METER

TAPE 2 J2
PLAY REC

DIN J1
REC/PLAY

TAPE 1 J3
PLAY REC

AUX J4-2

PUSH SW PC BOARD (AB-35103A)

TONE CONTROL PC BOARD (AB-35102)


TOUCH SW PC BOARD (AB-35104)

TOUCH SENSOR PC BOARD (AB-35105)

MULTI FUNCTION PC BOARD (AB-35101A)

VARI CON PC BOARD (AB-35101B)

LED PC BOARD (AB-35103B)



NOTE
UNLESS OTHERWISE SPECIFIED
ALL RESISTORS IN OHMS (1/4W1)
ALL CAPACITORS IN PFD (1/4)
(LL) INDICATES LOW LEAKAGE CAPACITORS

AA-1135L
SCHEMATIC DIAGRAM
No. 2-1 1560646A

MAIN AMP P.C. BOARD (AB-35101)