

A 6 9 2




Fig. 4. Schematic of the A-692 amplifier-speaker. Note the compensation network and tone control in the feedback circuit.

A 692





Fig. 4. Schematic of the A-692 amplifier-speaker. Note the compensation network and tone control in the feedback circuit.

2010/2012



NOTES

1. ALL RESISTORS ARE 1/2 WATT 10% UNLESS OTHERWISE SPECIFIED.
2. ALL CAPACITORS ARE 400 VOLTS UNLESS OTHERWISE SPECIFIED.
3. S1 SHOWN IN OFF POSITION.
 POSITION 2 - AC ON, TAPE CONNECTED TO AMPLIFIER.
 POSITION 3 - AC ON, TUNER CONNECTED TO AMPLIFIER & TAPE RECORD.
 POSITION 4 - AC ON, PHONO CONNECTED TO AMPLIFIER & TAPE RECORD.
 POSITION 5 - AC ON, TV CONNECTED TO AMPLIFIER & TAPE RECORD.
 TUNER, PHONO & TV INPUTS ARE GROUNDING WHEN NOT ACTIVE.