



SEE MANUAL

- ① 12AX7
- ② 12AU7
- ③ 12AU7
- ④ 6L6
- ⑤ 6L6
- ⑥ GREEN
- ⑦ GREEN-YELLOW (NOT USED) GREEN

105-125V  
50-60 AC

ON TREBLE  
CONTROL