



ALL SWITCHES SHOWN IN FULL "ON" POSITION AS VIEWED FROM FRONT
 "SELECTOR" SWITCH IS IN "TAPE HEAD" POSITION
 "MAG PHONO" SWITCH IS IN "OFF" POSITION
 *FOR SUBSTITUTION SEE INSTRUCTIONS BY CARTRIDGE MANUFACTURERS
 OF LEVEL, HEIGHT & CONTROLS

SCHEMATIC
HEATHKIT STEREO PREAMPLIFIER
MODEL SP-2
A CHANNEL PREAMPLIFIER AND POWER SUPPLY