



MILLMAN & CO., STA

FOR COMPONENT VALUES SEE SERVICE SHEETS

CIRCUIT DIAGRAM OF RC/PA/U PRE-AMPLIFIER

NOTE: TONE CONTROL POTENTIOMETER IS SET TO CENTER POSITION (0dB) FOR SERVICE SHEETS



REMOVE PLUG FITTING FROM 3 FROM ABOVE POINTS TO PREVENT SHORTING OF CABLE WHEN IN STORAGE

Fig. 2. TONE CONTROLS. These boosts and losses are available on all inputs. On 'Microphone' input the treble boosts are slightly less

