



ALIGNMENT INSTRUCTIONS

	SIGNAL GENERATOR	CONNECT SCOPE	ADJUST	REMARKS
1.	19KC to MPX Input.	Vert. Amp. to pin 2 of V3, low side to chassis.	A1	Adjust for maximum deflection.
2.	"	Vert. Amp. to pin 7 of V1, low side to chassis.	A2, A3	Adjust for maximum deflection. Set scope to 2-cycle waveform.
3.	"	Vert. Amp. to pin 1 of V2, low side to chassis.	A4, A5	Adjust for maximum deflection of 4-cycle waveform.
4.	67KC to MPX Input.	Vert. Amp. to pin 6 of V3, low side to chassis.	A6, A7	Adjust for MINIMUM deflection. A7 may be adjusted at 38KC for maximum.
5.	38KC to MPX Input	Vert. Amp. to Ch. A output jack, low side to chassis.	A8	Adjust for MINIMUM deflection.
6.	"	Vert. Amp. to Ch. B output jack, low side to chassis.	A9	"

KNIGHT KN-MX-3 (350DX863)